

# **MASTERS 247 Owners Manual**





# WELCOME TO THE SPORTSMAN TEAM!

Here at Sportsman Boats, we take great pride in producing the finest, most well designed, saltwater fishing and pleasure boats on the market today. Our designs incorporate the most modern technology while applying good old "Common Sense" technology as well. From our advanced composite construction, ergonomic console designs, patented "Total Access" hatch, and superior ride and handling characteristics, we think you will agree that Sportsman is setting a new standard.

We do not take lightly the confidence you have placed in us with your decision to purchase your Sportsman boat. We will always strive to provide for you and your family the superior customer service you deserve. We hope that you enjoy your time out on the water as much as we enjoy building your Sportsman boat!

Safe Boating and Tight Lines

Tommy Hancock and Dale Martin



SPORTSMAN

# MASTERS 247

Length	24'4"
Beam	<i>8'5"</i>
Max HP	300 HP
People Capacity	10
Fuel Capacity	71 Gallons
Rear Aerated Livewell	2 x 25 Gallons
Console Cooler	12 Gallons
Draft	14"
Deadrise @ Transom	15 Degrees
Approx Dry Weight	2750 lbs







SPORTSMAN





# **PERFORMANCE BULLETIN**

#### YPB#: PB\_SPT\_Masters247\_F250XA\_2013-06-03\_BAY





RPM	MPH	GPH	MPG
1000	5.6	1.3	4.31
1500	7.5	1.9	3.95
2000	9.3	3.0	3.10
2500	14.0	4.0	3.50
3000	22.1	5.1	4.33
3500	28.6	6.4	4.47
4000	32.7	8.5	3.85
4500	37.4	11.3	3.31
5000	41.4	14.2	2.92
5500	45.5	16.9	2.69
5950	51.4	23.3	2.21





# YAMAHA

#### Test Date 6/3/13 Sportsman\* Masters 247 24'4" 8'5" Dry Weight (Bost Mr. Pub) 2.750 lbs Maximum HP 300 **Fuel Capacity** 72 gal Weight as Tested 3 958 hs

#### F250XA Hors Indu

Disp

Weig

Gen

Serie Diam Yam Prop

Length Beam

sepower	250 HP
iction	EFI
vacement	3.3 L
gh1	608 lbs
r Ratio	2.00

#### ENGINE MOUNTING HEIGHT

Mounting Hole Position	12
Ventilation Plate Height	1" Above Boat Bottom

#### PROPELLER/S

05	Saltwater Series II-SDS
neter/Pitch	15-1/4 x 19
aha Part #	6CE-45970-00-00
eller Material	Polished Stainless Steel

#### TEST CONDITIONS

Number of People	2
Air / Water Temperature (Farverber)	75/80° F
Elevation (in feet above sea level)	Sea Level
Wind Velocity	0-5 mph

Comments: Test weight includes 1/2 tank of fact, 2 betteries, safety and test gear

Netse to Consumer: The information and data consumed in the Performance II Units is approximate and subject Tomary different factors and variables. It is provided as an guardine out ward stack to be relief upon as representable of acaut performance. Now backs performance may be defined to the information contrained in the Performance IBMeet data to variable stacks, recluing your back's actual weight, and and water conditions, Immersian, functing environment and an environment in the Performance IBMeet data to variable stacks, recluing your back's actual weight, and and water conditions, Immersian, functing environment performance and performance data on your specific documents with your double provide performance and acan your for your back's document to the performance and performance and performance data on your period. Documents with your double provide performance data only Terrate Persons and in the Anternance Dubletin re-opies of environment data comparison and and the anternance Dubletin re-solution terrates. The document contains many of thematic National terrates the style to manage the specifications and performance could all the anternance Dubletin re-solution terrates. The document contains many of thematic National terrates and taken before the document contains and performance could be the terrates and backment beforeing to other comparison. An environment Notice to Consumer. The microsoften and data contained in the Performance Bulletin is approximate

For more information Yamaha Motor Corporation, U.S.A. OEM Division, Marine Group 1270 Chastain Read NW Kennesaw, GA 30144 - (800) 58-YAMAHA For other Performance Bulletins, visit www.yamaha-molor.com

© 2013 Yamaha Motor Corporation, U.S.A. All rights reserved

# PERFORMANCE BULLETIN

#### YPB#: PB\_SPT\_Masters247\_F300XCA\_2013-06-03\_BAY



#### Beam Dry Weight (Boat Mr. Pub) Maximum HP **Fuel Capacity** Weight as Tested

Sportsman<sup>®</sup> Masters 247

#### F300XCA

Gear Ratio

Length


Sportsman Masters 247 F300 Yamaha Performance Bulletin 5

Sportsman Boat Manufactured By:

Sportsman Boals - PO Box 2100 - Summerville, SC 29484 843-376-2628 - www.sportsmanboatsmfg.com

RPM	MPH	GPH	MPG
1000	5.8	1.3	4.46
1500	7.8	2.2	3.55
2000	11.2	3.4	3.29
2500	20.5	5.0	4.10
3000	27.3	6.3	4.33
3500	33.0	8.5	3,88
4000	37.6	11.5	3.27
4500	42.7	15.5	2.76
5000	47.2	19.4	2.43
5500	51.7	22.8	2.27
5950	55.5	25.9	2.14
Time to Plane			





nduction Displacement Weight

#### ENGINE MOUNTING HEIGHT

Mounting Hole Position	12	
Ventilation Plate Height	1" Above Boat Bottom	

Sories	Saltwater Series II-SDS
Diameter/Pitch	15-1/4 x 19
Yamaha Part #	6CE-45970-00-00
Propetler Material	Polished Stainless Steel

Number of People	2
Air / Water Temperature (Faterbot)	75 / 80* F
Elevation (in feet above sea level)	Sea Level
Wind Velocity	0-5 mph

tafferios, optional hard top, safety and test goar

Nolice to Consumer: The information and data contained in this Performance Bullistic is approx Notice to Consume: The information and data consumed in the Vertimizers II. Initiation is approximate and subject Tomary Ulterent Initiation and waraktion. It is provided as in guardine or may be different be released upon as septementation of autual partimizers. Note tools performance must be different their the information continued on this Rectinearia. Building and the set of the set of

#### For more information

Yamaha Molor Corporation, U.S.A. OEM Division, Marine Group 1270 Chastain Read NW Kennesses (CA 20144 - (BOC) BA VAMANA For other Performance Bulletins, visit www.yamaha-motor.com.

© 2013 Yamaha Motor Corporation, U.S.A. All rights reserved

**WAMAHA** 

Test Date 6/3/13

24'4"

8'5"

300

72 gal

300 HP

EFI

4.2 L

1.75

562 lbs

4,241 bs

2,750 lbs

DATA		ENGINE MOUNTING HEIGHT Mounting Hole Position	
.3	4.46		
2.2	3.55	PROPELLER/S	
9.4	3.29	Sories	
5.0	4.10	Diameter/Pitch	
5.0	4.10	Yamaha Part #	
5.3	4.33	Propeller Material	
8.5	3,68	1.007779070010430001	
1.5	3.27	TEST CONDITIONS	
5.5	2.76	Number of People	
9.4	2.43	Air / Water Temperature (Faterbol)	
	0.07	Elevation (in feet above sea level)	
2.8	2.27	Wind Velocity	
5.9	2.14	2.5 C	
	3.35	Comments: Test weight includes 12 tank of fuel, 2	

4.28





# NMMA Certified

Sportsman Boats is certified by the National Marine Manufacturers Association (NMMA). NMMA certification not only meets the standards of the United States Coast Guard (USCG), but goes further and meets the standards set by the ABYC (American Boat and Yacht Counsel). All Sportsman models have been designed, constructed and thoroughly tested to meet or exceed these standards. For more information on the 2015 model year standards, you may visit <u>http://www.nmma.org/certification/programs/boats/</u> for more details.



# Hull Number / Registration

Sportsman has a permanent record of your boat. This record is documented during the manufacturing process. It is identified by its "Hull Identification Number" (HIN). The HIN is located on the starboard side of the transom, just under the Rub Rail. When contacting your dealer concerning maintenance or warranties, please have your HIN and model number available. This information can be found on your copy of the warranty card. Federal and State laws require a power boat to be registered in the state where it is primarily used. Registration numbers and validation stickers must be displayed according to regulations. The registration certificate must be on board when boating. The boat serial number, or Hull Identification Number (HIN), is required on the registration form. The HIN should be included on all documents or any correspondence.



Please fill out the following information. We recommend keeping one copy in your personal records and one copy with your owner's manual. This information will be important to you should you need to contact your Dealer or Sportsman Boats for technical assistance and/or service.



BOAT INFORMATION / SPECIFICATIONS		
MODEL:	HULL SERIAL #:	
PURCHASE DATE:	DELIVERED:	
IGNITION KEY #:	REGISTRATION #:	
DRAFT:	WEIGHT:	
VERTICAL CLEARANCE:		
ENGINE / PROPELLER INFO	RMATION	
ENGINE MAKE:	MODEL:	
ENGINE SERIAL #:		
PROPELLER MAKE:	# OF BLADES:	
DIAMETER / PITCH:	MODEL:	
PART #:		
<b>OPTIONAL EQUIPMENT / O</b>	PTION PACKAGES	
TRAILER INFORMATION		
MAKE:	MODEL:	
SERIAL #:	GVRM:	
ADDITIONAL INFORMATION:		
DEALER	SPORTSMAN	
NAME:	PHONE:	
PHONE:	REPRESENTATIVE:	
SALES PERSON:	ADDRESS:	
SERVICE MANGER:		
ADDRESS:		

SPORTSMA

# BOATING SAFETY REQUIRED SAFETY EQUIPMENT

The US Coast Guard (USCG) requires that every boat have specific equipment on board. Check with local regulations on mandatory equipment apart from the list of Coast Guard requirements.

5 PORTSINA

## FIRE EXTINGUISHER

At least one Type-1 hand held portable fire extinguisher must be carried on board. For boats over 20' two are required. Check extinguisher regularly for charge status.

## **PERSONAL FLOTATION DEVICE (PFD)**

You must have a USCG approved personal flotation device of Type I, II, or III aboard for each passenger, in addition to one Type IV throwable PFD. **Always wear a PFD when boating.** In some states, children are required to wear a PFD at all times. Check your local regulations.

#### SOUND SIGNALING DEVICES

Your Sportsman boat is equipped with an electric horn which meets the USCG requirements for a sound signal device.

#### **VISUAL DISTRESS SIGNALS**

USCG approved visual distress signals are required for day and night use when operating on US waters. Approved signals include flares, orange smoke, an orange distress flag, or an electric distress light.


#### LIGHTING

Your Sportsman boat is equipped with navigation lights which comply with both Inland and International rules.



SPORTSMAN

Being on the water is a great experience, but it can become a bad experience very quickly if safety and maintenance of your boat are not followed. Therefore, your Sportsman manual has been written to include a number of safety instructions and notices in order to help you operate and maintain your boat safely. These instructions are in the form of **WARNING** and **DANGER** statements. They are defined as follows:



Please become familiar with the location and content of the Caution, Warning, and Danger Labels found on your boat.





Your Owner's Manual was written to include safety instructions to ensure safe operations. Safety alerts symbols are used to show potential personal injury hazards.

Your boat produces carbon monoxide and uses flammable fuel. Carbon monoxide can cause brain damage or death. Carbon monoxide is colorless, odorless and extremely dangerous.

## **A** WARNING

ROTATING PROPELLER MAY CAUSE SERIOUS INJURY OR DEATH. DO NOT APPROACH OR USE LADDER WHEN ENGINE IS RUNNING.

## **A** WARNING

ROTATING PROPELLER MAY CAUSE SERIOUS INJURY OR DEATH. SHUT OFF ENGINE WHEN NEAR PERSONS IN THE WATER.

A WARNING			
	Carbon monoxide (CO) can cause brain damage or death. Engine and generator exhaust contains odorless and colorless carbon monoxide gas. Signs of carbon monoxide poisoning include nausea, headache, dizziness, drowsines and lack of consciousness. Get fresh air if anyone shows signs of carbon monoxide poisoning. See Owner's Manual for information regarding carbon monoxide poisoning.		Carbon monoxide (CO) can cause brain damage or death. Engine and generator exhaust contains odorless and coloriess carbon monoxide gas. Carbon monoxide will be around the back of the boat when engines or generators are running. Move to fresh air, if you feel nausea, headache, dizziness, or drowsiness.

Every precaution has been taken to reduce the risks associated with death, possible injury, damage from fire/explosion. Your own precaution and proper maintenance procedures are necessary in order to enjoy safe operation of your boat.


If your label is damaged. You can call Sportsman's parts department for replacement stickers

# MEETS U.S. EPA EVAP STANDARDS USING CERTIFIED COMPONENTS

Sportsman Boats Mfg. Summerville, SC


# **A** WARNING

AVOID SERIOUS INJURY OR DEATH FROM FIRE OR EXPLOSION RESULTING FROM LEAKING FUEL. INSPECT SYSTEM FOR LEAKS AT INSPECT SYSTEM FOR LEAKS AT





# Masters 247 has a 10 Person Capacities, below shows the seating/standing locations







# Your electrical system:









# **Fuse Panel**

PORTSMA

Is located under the console. Clearly labeled for easy identification. In the same area you will find a 6 amp fuse for your bilge pump. You will also find a 30 amp breaker coming off the main battery switch. This would be the first place you look if a component stops working.





 Introduced Simrad NSS EVO2 Multi function display into all boat lines and models

DATISMA

- EVO2 integrates all the functions of the boat:
  - Engine Instruments
  - Navigation
  - Coastal Charts
  - Sonar
  - Sonic Hub/Fusion Stereo
  - Radar Capability
  - Structure Scan Capability





Your Sportsman 247 Master comes with a Standard 7" Simard Unit. The Transducer is located on the hull bottom at the stern of your boat. The Sonic Hub Radio is an option on your 247. If installed you can controlled through your Simrad display unit. The Sonic Hub is located inside your console.



# **Bilge Pump**

Located on the hull bottom at the stern of your boat. Water is pumped out of a thruhull-fitting located on the starboard side of the hull near the transom. Pump may be accessed by lifting the total access hatch. You may turn your bilge pump on manually with your bilge switch located on the switch panel at the helm of your boat. Once water in the bilge area reaches a certain level, the float switch is automatically engaged and the bilge pump is activated.

SPOLATSIMIA

Bilge pumps are designed to remove excess water only. They are not intended to prevent rapid accumulation of on-board water due to rough weather, hull damage, or other unsafe navigational conditions.



**All-round/Anchor light:** Is a white light placed over the highest unobstructed point of the vessel, showing an unbroken light over an arc of the horizon of 225 degrees and fixed to show from anywhere ahead, to just behind the beams of the vessel.


**Sidelights:** Your Masters 227 has integrated rub rail navigational lights installed at the bow. A green light is located on the starboard (right) side and a red light on the port (left) side of the vessel. Each shows an unbroken light over an arc of the horizon of 112.5 degrees and is fixed to show from ahead to just behind the beams of the vessel on its respective side.

The Nav/Anc switch is a 3 position switch that controls the running lights.

\*NAV position will turn on the red and green navigation lights and the white all-round light for night driving.

\*ANC turns on the all-round light only for night anchoring, do not operate the boat in the anchor position

*\*Off is in the center position* 




5-POLATSIMA

Recreational boats are required to display navigation lights between sunset and sunrise and other periods of reduced visibility (fog, rain, haze, etc.) Navigation lights are intended to keep other vessels informed of your presence and course. Your boat is equipped with the navigation lights required by the U.S. Coast Guard at the time of manufacture. It is up to you to make sure they are visible, operational and turned on.






Your 247 comes with (2) 25 gallon livewells and a 12 gallon console livewell. The pumps are located next to the bilge in the hull of your boat. Open the total access hatch for easy access. You may operate your livewells by opening the high speed pickup valve in the bilge area of your boat. Then turn on your switch labeled livewell 1 on your helm switch panel to operate the starboard aft and the livewell under the Front Seat of Console . Then turn on your switch labeled livewell 2 on your helm switch panel to operate the Port aft livewell. The livewell has a overflow drain so water will not exceed a specified level. Also, LED lights are installed in each livewell for Illumination by turning on the switch at the dash.







The 247 comes with a 71 gallon fuel tank. The gasoline fuel system consists of a fuel tank, fuel tank vent, anti-siphon valve, engine fuel supply line, and fuel fill. Your boat contains a new EPA certified fuel system. *The system prevents* spit back when filling the tanks and lowers the out gassing emissions through the tank and vent.








#### BLUSKIES DIURNAL FUEL SYSTEMS OPERATION

#### Emissions And Vapor Management

Based upon the location and time of year, the sun, during its orbital path around the USA subsequently causes the ambient temperature to rise and fail. This is referred to as the durnal temperature cycle. If this durnal temperature cycle creates sufficient heat to cause the temperature of gasoline in a gasoline tank to fae, then the gasoline will expand up to a maximum rate of ~5%. Additionally this event causes fael vapors (or hydrocarbons) to vert of to atmosphere.




For marine fuel tankalsystems to be compliant to the Environmental Protection Agency (EPA) regulations, tael vapors (emissions) from books must not be allowed to evaporate unfettered through a test system verif during the head of a diamal temperature cycle. To manage these emissions boatbuilden have two basic options: 1. they can passively purge (PIG. 1.) the vapors by installing a series of charcoal filed canistes that/waitcapitore vapor (hydrocarbons) during diamal venting. Or: 2. they can manage these vapors via a vapor relief (PIG.2.) system that allows vapors to be released ~ PDSIG (~2intig). Both options creates a small pressure (or back pressure) build up at dismal pask temperature cycles and both options must carry a "Cestificate Of Compliance" issued by the EPA.



#### Vapor Space (Ullage) And Refueling Management

Another fuel system necessity to remain EPA compliaint it is to keep elevated temperature gasoline from expanding into fuel system areas that are notice permeation rated or otherwise aerative to nee fuel. A vapor (or ullage) space mustbe produced at the completion of the filing or refueling operation to ensure systems remain EPA compliant during the diurnal temperature cycle. To effectively manage this system function, BluSkies has created a series of valves that can mount to any marine fuel tank to achieve the appropriate fill level while maintaining ullage space of ~5%. Additionally these valves eliminate the propersity for refueling 'spit-back' or tank 'well-back', which is another requirement of the EPA regulation. BluSkies primary ullage valves replace the existing fill and vent locations, while additional grade or tip level valves can be added to any tank to meet American Boal And Yacht Council atandards. (H-24) which alives, vapor venting for boats stanting or aloging when stored, mocred, parked or trainered.



#### Ullage achieved, fuel shut off engaged

The final decision on which system type and ullage valve type and placement that is best for your application should be based on application specific factors such as type and configuration of fuel tank, how much room there on board is for added components, how are the boats likely to be used and storedetc, and of course cost.

Choose individual components to create a compliant system from the following pages or you can turn to our specialists for sound guidance and direction as you go through the process to choosing the appropriate system for your particular vessel application.



SPOLITSMAN

Raw water washdown is standard with both the Platinum and Sport option packages on your new 247. Rinsing your boat immediately with a powerful water jet washdown makes a fine addition to almost any boat.

*The raw water system supplies water* by a hose connected to a pump with a shut off valve on your high speed pick up in your bilge compartment. The bottom hose on the pickup is for the raw water system. The pump can easily be accessed when you open your total access hatch. You can operate your washdown by opening the valve handle on the high speed pick up in the bilge area of your boat. Then turn on your switch labeled washdown on the helm of your boat. The washdown outlet can be found on the Starboard side of the Motor Pan.



SonicHub Stereo Media device option. It takes your music onboard and allows you to experience the ultimate in marine audio with Bluetooth streaming connectivity from any enabled media device to the SonicHub module -- allowing control of your favorite selections directly from your Simard unit. The SonicHub is located inside the console. This allows more space on your console and keeps your stereo protected from the elements

*If the stereo option was purchased the 247 comes with 4 marine grade Infinity speakers.* 



JPDRITSMA





SPORTSMAN

Trim Tabs come standard on your Masters 247. They are attached to the bottom edge of the transom. When the helm control is pressed, the trim tabs move into position. Water-force on the trim tab surface creates upward pressure, raising the stern and lowering the bow. Trim Tabs improve the performance of your boat in a much wider range of weight, weather and water conditions.

The top portion of the Left switch is marked Port/Bow Down. Pushing this switch deploys the right tab and its movement is indicated by the Left set of the red LED's. All LED's lit is down. The other 3 switches, operate in the same manner, for port and starboard, bow up and bow down. These switches can be pushed individually. Simultaneously or cross controlled, as appropriate.





Fresh water is an option on the 247, but comes standard with both the Platinum and Sport packages

• The freshwater tank and fill are located in the bow under the center lid.

• Pressurize the freshwater system by turning On the freshwater pump switch on the helm.

•The freshwater pump switch is marked ACCESSORY 2 on the helm switch panel.

• Turn Off the freshwater pump switch when your boat is not in use or when the freshwater tank is empty.

•Your pump with filter is mounted inside your console on the starboard side

•Inspect and clean the freshwater filter often (the filter is located on the freshwater pump).

•If your boat is to be left unattended for a long period of time, pump the freshwater tank dry to prevent stored water from becoming stagnant and distasteful.








# OPTIONS: Fiberglass Top With LED Lighting Included In The Platinum Package



Fiberglass Top option comes with the Platinum package. The T-Top switch turns on the 3 blue courtesy lights. The SPREADER switch operates the 2 back spreader lights and the front spreader light. The switch on the map light may be turned one way for a red or the other way for a white light.







SPREADER

ACCESSORY

DETENA

Underwater lights are option. They can be operated with the ACCESSORY 1 switch. These High-Intensity LED Underwater Lights are totally waterproof. A broad flood light effect is created by the engineered optics of the convex light face.









#### **Rules When Encountering Vessels**

There are three main situations that you may encounter with other vessels which could lead to a collision unless the Steering Rules are followed:

- •Meeting: you are approaching another vessel head-on
- •Crossing: you are travelling across the path of another vessel
- •Overtaking: you are passing or being passed by another vessel


<u>When Crossing</u>: Every boat has a "Danger Zone" from straight in front (the bow) to past the middle of its right side. Like when meeting another car at a street intersection, the one on the right has the right of way. You must yield to boats in your Danger Zone. If you are the skipper of the Vessel A in the center of the diagram, you must keep out of the way of any boat that approaches you from any direction within the indicated Danger Zone, as you are the burdened craft. Likewise, boats approaching you from all other directions, except the meeting vessel, must keep clear of you.

<u>When Meeting Port-to-port</u>: Continue on course. The same holds true for meeting starboard-tostarboard.

<u>When Meeting Head On</u>: As in a car, both stay to your right and as far apart as practical. Each boat should turn to starboard and pass port-to-port.

<u>When Overtaking Another Boat</u>: The boat being overtaken is the privileged vessel. Only after signaling and receiving an acknowledgment can the overtaking boat pass. (Use on blast to pass on the right, and two blasts to pass on the left.

<u>When Being Overtaken</u>: Be ready for trouble when a power boat passes you in a narrow waterway. As the lead boat, which always has the right of way, stay on your side of the channel and maintain a steady speed so that the overtaking vessel can pass you safely. Use your radio to discuss this with the passing boat.



# **Product Changes**

Sportsman is committed to the development of our product line. As a result, equipment described in this manual may have changed or no longer may be available. All information, illustrations and specifications contained in this manual reflect the latest product information available at the time of publication. Sportsman reserves the right to make changes to its boats at any time, without notice. These changes include, but are not limited to: color options, materials, standard and optional equipment, specifications and model availability. If you have any questions about the equipment on your boat, please feel free to contact Sportsman.

JPDATSMA

# <u>Service</u>

All warranty work must be performed by an authorized Sportsman Dealer. If a problem is discovered upon taking delivery of, or develops during routine use of the boat that is related to faulty workmanship and/or materials, as stated in the warranty, you need to contact your Sportsman dealer to arrange for your boat to be repaired. **The boat owner is responsible for delivering the boat to the dealer for warranty service**. If you are not near your dealer or any other authorized Sportsman dealer, please contact Sportsman. Likewise, if the dealer fails to repair the problem, please notify Sportsman within 14 days of the work being completed. **Sportsman will not reimburse owners for unauthorized warranty work**.

# <u>Insurance</u>

In most states, the boat owner is legally responsible for damages or injuries they or anyone else operating the boat causes. Some states have laws that require having at least minimum coverage. Before using your boat for the first time, you should contact your dealer, current insurance company, or state boating authority for information regarding insurance requirements in your area. Although it may not be required in your area, responsible boat owners carry liability and property damage for their boat. You should also protect the boat against physical damage and theft.



#### SPORTSMAN BOATS LIMITED WARRANTY

**Ten-Year Hull Limited Warranty:** This limited Warranty applies to any Structural Hull Defect (as that term is defined below) if such is due to a failure in material or workmanship and the was reported to Sportsman according to the terms of this Limited Warranty within ten (10) years from the date of the sale to the original purchaser of the Sportsman authorized dealer. Sportsman, in its sole discretion, will either repair or replace the Hull. For purposes of this Limited Warranty, the term *"Hull"* shall mean the single fiberglass molded shell and integral structural components of a Sportsman Boat, and the term *"Structural Hull Defect"* shall mean a substantial defect in the Sports Boat's Hull that causes the boat to be unfit or unsafe for general use as a pleasure craft under normal operating conditions.

<u>One Year Nonstructural Limited Warranty</u>: This Limited Warranty applies to any Nonstructural Defect (as that term is defined below) if such is due to a failure in material or workmanship and the same was reported to Sportsman according to the terms of this Limited Warranty within one (1) year from the date of the sale to the original purchaser of the Sportsman Boat by a Sportsman authorized dealer. Sportsman, in its sole discretion, will either repair or replace the defective component. For purpose of this Limited Warranty, the term *"Nonstructural Defect"* shall mean a substantial defect in a Sportsman Boat's components manufactured or installed by Sportsman (other than the Hull) that is not excluded in the exclusions below.

**Registration and Transfer of Limited Warranty:** Each original purchaser of a Sportsman Boat shall complete and return the boat registration card provided by Sportsman within thirty (30) days of such owner's purchase of the boat in order to facilitate the processing of warranty claims and for manufacture notification. Except where a Sportsman Boats has been salvaged and resold after a declaration of a total loss or a total loss or a constructive total loss, this Limited Warranty is transferrable to a subsequent owner of the Sportsman Boat. PROVIDED SUCH SUBSEQUENT OWNER FILL OUT AND SEND TO SPORTSMAN A SPORTSMAN WARRANTY TRANSFER FORM (AVAILABLE FROM SPORTSMAN ON REQUEST). A COPY OF THE BILL OF SALE, WHITHIN THIRTY (30) DAYS OF SUCH TRANSFER OR PURCHASE.

#### EXCLUSIONS

This limited Warranty does not apply to any boat that has been salvaged or declared a total loss or constructive total loss for any reason not specifically covered in this Limited Warranty. In addition, this Limited Warranty does not apply to the following "*Exclusions*"

1) A Hull, component, or other product that has been repaired without authorization of Sportsman or that has been altered in any way that affects its use and operation;

2) Expenses related to inspection or warranty service for hauling out, transportation to and from any dealer or Sportsman factory, towing or storage changes, inconvenience or loss of time or income;

3) Engines, outdrives, controls, propellers, engine brackets, stereos, depth finder, GPS units, trolling motors, batteries, outriggers bases' and other equipment or accessories that are not manufactured by Sportsman, whether the same is or is not warranted by such other manufacturer;

- 4) Blistering, discoloring, cracking, or crazing of the Gelcoat finish or other surface finishes
- 5) Any Sportsman Boat initially sold at retail by a party other than an authorized Sportsman dealer;
- 6) Damage to, breakage of, or leakage around any windshields, hatches, or apertures;
- 7) Any canvas, zippers, vinyl, upholstery, plastic, or fabric components;
- 8) Discoloration, oxidation, bleeding, or corrosion of any stainless steel or other metal products

9) Any Hull, component, or product that has been subject to unreasonable use, tampering, abuse, mishandling, improper maintenance, negligence, improper trailing, alterations, or accidents; 10) Any boat, or component or part thereof, that has been used for Commercial Purpose, racing purposes, or has otherwise been operated contrary to any printed instruction provided by Sportsman or contrary to any applicable law (for purposes of this Limited Warranty, the term *"Commercial Purposes"* shall mean the usage of any boat more than fifty percent (50%) for revenue-producing or other business purposes);

11) A boat, or component or part thereof, that has been overpowered according to the maximum recommended engine horsepower specified on the capacity plate attached to the boat;

12 )Machinery, equipment and accessories not installed by Sportsman;

13) Condensation of gauges;

14) The failure of any par, area, or component of the boat to be dry, whether or not the same was represented as "dry";

15) Any representation relating to the speed or weight of any part or component of the boat;

16) Normal wear and tear maintenance items, including, but not limited to, filters bulbs, batteries, bungees, anchor rope, trailer finishes, tires, brakes, bearing, and lights;

17) Any defect or repair requiring redesign of the boat, except pursuant to the recall provisions of the United States Federal Boat Safety Act of 1971 or the recall laws of the recall laws of any other foreign jurisdiction;

18) Dealer preparation, cleaning, and final adjustments and alignments in preparing the boat for delivery or commissioning; or

19) Any act of God or force majeure.



Thank you for your purchase of your Sportsman Boat. Please contact us at any of the following:

Sportsman Boats Manufacturing, Inc. 113 Issac Way Summerville, SC 29483

Office:843-376-2628 Fax: 843-376-2636

P.O. Box 2100 Summerville, SC 29484 Email: <u>sales@sportsmanboatsmfg.com</u> Visit:www.sportsmanboatsmfg.com

